
Data Sheet: Cover feeder 'Auto-loader' CAL-101

The optional CAL-101 Cover 'Auto-loader' increases the number of covers that may be loaded into the Smart-binder Cover Feeder from 20mm to 200mm pile height. This greatly extends the time between reloads and also improves the feed reliability:



The operator may load a large quantity of covers (up to 200mm pile height) into the CAL-101 Auto-loader. The covers feed out automatically from the bottom of the Auto-loader in a 'shingled' stream.

The pile height sensor automatically advances the CAL-101 Auto-loader friction belt when more covers are needed in the feed hopper. The cover pile height in the feed hopper remains at a constant low level, which improves feed reliability by avoiding excess pressure on the bottom cover when a new stack of covers is loaded.

The Auto-loader may not be able to feed sheets with cut-out 'windows' (covers with windows should be loaded directly into the cover feeder).